Jameco Part number 151829



Jameco Part number 151829

Contents

Preface XI

Section 1. Choosing the Parts 1

So You Want to Build Your Own PC 1
Disadvantages 2
Advantages 2
The bottom line 2
Deciding to Upgrade 3
Disadvantages 3
Advantages 4
Upgrading by troubleshooting 4
Remember to recycle 4
The Issues with Troubleshooting 5
Disadvantages 5
Advantages 5
The golden rule of troubleshooting 6
The Contemporary PC 6
Case 7
Power supply 7
Motherboard 8
Drive system 9
Video system 10
Sound board 11
I/O ports 12
Game port 12
Mouse and keyboard 12
Cases and Power Supplies 13
Cases 13
Power supplies 17

Jameco Part number 151829

Motherboards and Related Parts 21
Form factor 23
Expansion slots and buses 23
CPU support 26
Main memory (RAM) support 32
BIOS support 38
Chipsets and controllers 40
Choosing a motherboard upgrade 47
Video System 49
Video controllers 49
Monitors 52
Sound Boards 53
Sound issues 54
Drive Systems 56
Drive controllers 56
SCSI controllers 57
Floppy drives 61
Hard drives 62
CD-ROM drives 64
DVD drives 65
Other drives 68
Modems 69
Modem issues 70
Input Devices 72
Mouse 72
Keyboard 73
Joystick 74

Section 2. Starting the Assembly 77

PC Builder's Checklist 77
Tips for buying 79
Tools and materials 80
Static precautions 81
Boot disk 82
Work area 84
Electrical safety 84
Case and Power Supply Assembly 85
Step 1: Assemble the case 85
Step 2: Install the power supply 87
Assembling the Main Board 88
Step 3A: Motherboard installation 88
Step 3B: Case wiring 90
Step 3C: CPU installation 92
Step 3D: Ram installation 96
Step 3E: Cache RAM installation 105
Step 3F: CMOS battery installation 106

Jameco Part number 151829

Motherboard Problems and Troubleshooting 108
Completing the Initial Assembly 112
Step 4: Video system installation 112
Step 5: Keyboard installation 116
Step 6: Floppy drive system installation 118
Step 7: Initial testing 121

Section 3. Finishing the Assembly 127
Setting Up the Hard Drive 127
Step 8: Hard drive system installation 128
Step 9: Copy the DOS files 143
Step 10: Create your start-up files 144
Setting Up the Mouse 147
Step 11: Install the mouse 147
Setting Up for Multimedia 150
Step 12: Assemble the sound system 150
Step 13: Assemble the CD-ROM drive system 156
Step 14: Wrapping up the initial hardware 162

Section 4. Installing the Operating System 165
Installing Windows 95 165
Step 15: Getting ready for the installation 166
Step 16: Make a start-up disk 168
Step 17: Dealing with installation and backup problems 169
Step 18: Optimizing Windows 95 174
Supplemental Installations 179
Step 19: Installing a modem 179
Step 20: Installing a second hard drive 182
Step 21: Installing a joystick 185
Step 22: Installing a DVD-ROM drive 189
Step 23: Upgrading the BIOS 198

Appendix A. Understanding CMOS Features 203

Appendix B. Summary of Current Standards 229

Appendix C. PC Preventive Maintenance 231

Appendix D. List of PC Acronyms 251

Index 263

Jameco Part number 151829

Index

Accelerated Graphic Port (AGP), 16,25
access time (DVD drives), 189
acronyms (list), 251-261
advanced chipset menu (CMOS Setup), 216-217
Advanced Micro Devices (AMD), 27-29
Advanced Power Management (APM), 229
AGP (*see* Accelerated Graphics Port)
air intake, cleaning, 236
alignment, CPU, 96
AMD (Advanced Micro Devices), 27-29
APM (Advanced Power Management), 229
Application-Specific ICs (ASICs), 40
assembly, PC, 77-163
boot disk for, 82-84
burn-in, 163
buying components, 79-80
case, 85-86, 90-92
CD-ROM drive system, 156-162
drivers, 158-160
installation, 157-158
interface, choice of, 156-157
testing, 160
troubleshooting, 160-162
CMOS battery, 106-108
CPU, 92-96
alignment, 96
clock speed, 93, 94
heat sink/fan, 93, 95
sockets, 96
voltage jumper, 92-93
and electrical safety, 84-85
floppy drive system, 118-121
controllers, 118-119
drive, installing, 119
troubleshooting, 119-120
hard drive setup, 127-147
bootable, making drive, 138
configuration, 132-135
controllers, 128-130, 143
DOS files, copying, 143-144
extremely large drives, 138-140
formatting, 138
geometry figures, 132
mounting, 134
multiple drives, 137, 182-184
partitioning, 135-137
SCSI drivers, 141
and SCSI vs. EIDE, 130-131
startup files, creating, 144-147
testing, 141
translation software, 140-141
troubleshooting, 142-143
and initial testing, 121-126
keyboard, 116-117
last-minute checks, 162-163
modem, 179-182
drivers for, 179-180
external, 180
internal, 181-182
motherboard, 88-90
troubleshooting, 108-111
mouse, 147-150
parts checklist for, 77-79
power supply, 87-88

Jameco Part number 151829

RAM, 96-106
 bank, filling in, 98-99
 cache RAM, 105-106
 and memory parity, 104-105
 and SIMM combinations, 99-104
 snapping in SIMMs/DIMMs, 97-98
sound system, 150-156
 configuration, 150-152
 installation, 152-153
 and PnP technology, 153
 software, installing, 153-154
 troubleshooting, 154-156
static precautions with, 81-82
tools for, 80-81
video system, 112-116
 controller board, 113, 114, 116
 monitor, connecting, 113
 ports, 112-113
 resolutions, choosing, 113-114
 troubleshooting, 114
 work area for, 84
AT Attachment-3 Interface (ATA-3), 229
ATA Packet Interface (ATAPI), 229

ATA-3 (AT Attachment-3 Interface), 229
ATX specification, 16, 230
 power connections for, 19
audio (See also sound board(s))
 CD, 65
 DVD, 66-67
AUTOEXEC.BAT, 145-147, 168

Baby AT specification, 15-16
 power connections for, 18-19

baby cases, 13
backup drives, 9, 68-69
banks, memory, 35, 98-99
barrel batteries, 108
Basic Input/Output System (BIOS), 9, 25, 38-39
 autodetection of EIDE hard drives by, 132
 SCSI, 60
 upgrading, 198-201
 video BIOS, 51
 virus checking by, 166-167
battery, installing CMOS, 106-108
BEDO RAM (Burst Extended Data Output RAM), 33
beep codes, 108-111, 125
BIOS (see Basic Input/Output System)
books, 190
boot disk, 82-84
 updating, 247
boot options menu (CMOS Setup), 208-211
bootable drive, creating, 138
buffered data transfer rate, 190
burn-in, 163
Burst Extended Data Output RAM (BEDO RAM), 33
bus mouse, 72, 148
bus speed, 93
buses (*see* expansion slots/buses)
buying PC components, 79-80

cable(s):
 checking, 163
  exterior cables, 239
  interior cables, 245
 floppy drive, 61
 hard drive, 62, 129-130, 134
 second hard drive, 183
 power connectors, 18-19
cache on a stick (COAST) module, 35-36
cache RAM, 35-36
 installing, 105-106
case(s), 7, 13-17
 assembly of, 85-86
 baby, 13
 cleaning, 236
 desktop, 14
 drive bays in, 14-15
 manufacturers of, 17

Jameco Part number 151829

mechanical specifications, 15-16
tower, 14
upgrading, 7, 86
CD audio connector (sound board), 54, 55, 151-152
CD-ROM drive(s), 64-65, 156-162
checking tray of, 241
and choice of interface, 156-157
drivers, 158-160
DVD drive compatibility with, 190-191
installing, 157-158
optimizing, under Windows 95, 178-179
reassigning drive letter for, 184-185
testing, 160
troubleshooting, 160-162
Central Processing Unit (CPU), 26-32
AMD, 28-29
checking, 246
clock speed of, 26, 31
cooling, 30
Cyrix, 29
installing, 92-96
alignment, CPU, 96
and clock speed, 93, 94
heat sink/fan, 93, 95
sockets, 96
voltage jumper, 92-93
Intel, 27-28
upgrades of, 31-32
voltages for, 30-31
checklist, builder's, 2-3
chipsets, 40-45
manufacturers of, 45
cleaning, 235-238
air intake, 236
case, 236
and choice of cleaner, 235
fans/filters, 244
floppy drive, 240
keyboard, 237
monitor, 237-238
mouse, 238
speakers, 236-237
tape drive, 240-241
clock speed, 26, 31, 93, 94
clusters, 136
CMOS battery, installing, 106-108
CMOS Setup, 37, 183-184, 203-227
advanced setup menu, 211-223
advanced chipset menu, 216-217
event logging menu, 221-223
peripheral configuration menu, 212-215
plug-and-play configuration menu, 219-221
power management menu, 217-219
configuring hard drive in. 134-135
exit menu, 226-227
main screen, 203-211
boot options menu, 208-211
floppy options menu, 205
primary/secondary IDE menus, 206-207
security menu, 223-226
COAST (cache on a stick) module, 35-36

coin cells, 107
color depth, 50
color purity of monitor, checking, 242-243

COMMAND.COM, 144
compatibility, and upgrades, 3-4
complete backups, 233
components, PC (*see* parts, PC)
compressed air, 235
CONFIG.SYS, 144-147, 168
connectors, power, 18-19
controllers:
drive, 56-57
installing, 118-119
upgrading, 120
on-board, 46-47
SCSI, 57-61
video, 10, 47, 113, 114, 116

Jameco Part number 151829

costs:
of building a PC, 1, 2
repair, 5-6
of upgrades, 4
CPU (see Central Processing Unit)
customization, 2
Cyrix, 29

data protection, 231-235
CMOS backups, 234-235
file backups, 232-234
frequency of, 233
requirements for, 232
tips for, 233-234
types of, 233
data transfer rate (DVD drives), 189-190
dead system, 124
Defrag utility, 248
desktop cases, 14
Desktop Management Interface (DMI), 230
DIMMs, 37
installing, 98
DMI (Desktop Management Interface), 230
DOS, 67, 83-84
DRAM (*see* Dynamic RAM)
drive bays, 14-15
drive controllers, 56-57
installing, 118-119
upgrading, 120
drive power cables, 18
drive system, 9-10, 56-69
backup drive, 68-69
CD-ROM drive, 64-65
controllers, 56-61
DVD drive, 65-68
floppy drive, 61
hard drive, 62-64
mountings, checking, 246
drivers:
CD-ROM drive, 158-160
DVD drive, 195-196
joystick, 186-187
modem, 71-72, 179-180
mouse, 148
SCSI, 141
video system, 51
DVD drive(s), 10, 65-68, 189-198
access time of, 189
books, 190
and CD compatibility, 190-191
data transfer rate of, 189-190
disk care, 191-192
drivers, 195-196
installing, 192-196
troubleshooting, 196-198
Dvorak keyboard, 74
Dynamic RAM (DRAM), 32-33
Synchronous (SDRAM), 33-34

edges, sharp, 85-86
EDO RAM (*see* Extended Data Output RAM)
EIDE hard drives
controllers, 57, 130-131
huge, 138-140
El Torito, 230
electricity
safety issues with, 84-85
static, 81-82
EMM386.EXE, 144, 146, 147
Enhanced Parallel Port (EPP), 230
ergonomics, of keyboard, 74
event logging menu (CMOS Setup), 221-223
exit menu (CMOS Setup), 226-227
expansion slots/buses, 23-26
AGP, 25
checking, 244-245
ISA, 24
number of, 26
PCI, 24-25
USB, 25-26
VLB, 24
Extended Data Output RAM (EDO RAM), 33, 37
extended DOS partitions, 137
exterior of PC, checking, 238-243
cables, 239
CD tray, 241
color purity of monitor, 242-243

Jameco Part number 151829

floppy drive, 240
sound system, 241-242
tape drive, 240-241
external drive bays, 14
external modems, 70, 180
EZ-Drive, 140-141

fans, 30, 86
checking, 243-244
cleaning, 244
installing, 93, 95
Fast Page Mode RAM (FPM RAM), 33
FAT (File Allocation Table), 136-137
FDC (*see* floppy drive controllers)
FDISK, 136, 184
File Allocation Table (FAT), 136-137
file backups, 232-234
frequency of, 233
requirements for, 232
tips for, 233-234
types of, 233
filters, 86
cleaning, 244
firmware, 198
flashing, 199-201
floppy drive controllers (FDCs), 46, 129
floppy drive(s), 61
cleaning, 240
installing, 118-121, 119
nonlocatable, 126
troubleshooting, 119-120
upgrading, 120-121
floppy options menu (CMOS Setup), 205
form factors, 15, 23
formatting, of hard drive, 138
FPM RAM (Fast Page Mode RAM), 33

game ports, 12, 75, 152
geometry, hard drive, 132

hard drive controllers (HDCs), 46-47, 128-130
upgrading, 143
hard drive(s), 62-64
cable, 62, 129-130, 134
installing second, 182-184
jumpers, 62-63
maintenance of, 246-248
boot disk, updating of, 247
Defrag utility, running, 248
ScanDisk utility, running, 247-248
manufacturers, 63-64
optimizing, under Windows 95, 175-178
parameters, 63
preparing, for Windows 95 installation, 167
setup of, 127-147
bootable, making drive, 138
configuration, 132-135
controllers, 128-130, 143
DOS files, copying, 143-144
extremely large drives, 138-140
formatting, 138
geometry figures, 132
mounting, 134
multiple drives, 137, 182-184
partitioning, 135-137
SCSI drivers, 141
and SCSI vs. EIDE, 130-131
startup files, creating, 144-147
testing, 141
translation software, 140-141
troubleshooting, 142-143
HDCs (*see* hard drive controllers)

heat sinks, 30
installing, 93, 95
HIMEM.SYS, 144-147
hot insertion and removal, 26
HyperTerminal, 71

ICs, Application-Specific, 40
incremental backups, 233

Jameco Part number 151829

Industry Standard Architecture (ISA), 24
initialization, problems with, 125
input devices, 72
(*See also* joystickk(s); keyboard(s); mouse)
input/output (I/O) ports, 12
Integrated Services Digital Network (ISDN), 71
Intel processors, 27-28
interior of PC, checking, 243-246
cables, 245
CPU, 246
drive mounting, 246
expansion boards, 244-245
filters, 244
memory, 245-246
internal drive bays, 14-15
internal modems, 70, 181-182
Internet, 69-70
purchasing over, 80
I/O (input/output) ports, 12
Iomega Ditto drive, 69, 232
Iomega Zip drive, 68-69
ISA (Industry Standard Architecture), 24
ISDN (Integrated Services Digital Network), 71

joystick(s), 74-76, 185-188
attaching, 185-186
drivers, 186-187
troubleshooting, 187-188
jumpers
DVD, 66
floppy drive, 61
hard drive, 62-63

K5 CPU, 28-29
K6 CPU, 29
keyboard(s), 12-13, 73-74
cleaning, 237
installing, 116-117
troubleshooting with, 117
upgrading, 117
keyboard port, 46
Klamath, 28

M1 CPU, 29
M2 CPU, 29
maintenance, preventive (*see* preventive maintenance)
Management extension hardware, 230
manufacturers:
of BIOS, 39
of cases, 17
of CD-ROM drives, 65
of chipsets, 45
of drive controllers, 57
of DVD drives, 68
of floppy drives, 61
of hard drives, 63-64
of joysticks, 73-74
of keyboards, 74
of memory, 38
of modems, 72
of monitors, 53
of motherboards, 47-49
of pointing devices, 73
of power supplies, 20
of SCSI controllers, 60-61
of sound boards, 55-56
of video boards, 52
master, 132-133, 182-183
Master Boot Record (MBR), 172-173
memory:
adjusting virtual, under Windows 95, 176-178
checking, 245-246
manufacturers of, 38
MIDI, 55
upgrading, 36-38
video, 50-51
[*See also* Basic Input/Output System (BIOS); Random Access Memory (RAM)]
memory banks, 35, 98-99
memory parity, 104-105
MIDI memory, 55
MIDI/game port (on sound card), 54-55, 152
MMX (Multimedia Extension), 27-28
modem(s), 69-72
drivers, 71-72, 179-180
installing, 179-182
internal vs. external, 70

Jameco Part number 151829

manufacturers, 72
speed, 71
monitor(s), 52-53
checking color purity of, 242-243
cleaning, 235-236
connecting, 113
motherboard, 8-9, 21-26, 38-49
BIOS, 38-39
chipsets/controllers on, 40-47
drive controllers on
disabling, 128-129
floppy drive controller, 118
using, 128
expansion slots/buses on, 23-26
form factor, 23
installing, 88-90
manufacturers of, 47-49
ports, 45-46
repairs of, 111
troubleshooting, 108-111
upgrades of, 47
mounting points (power supply), 19-20
mouse, 12-13, 72-73
cleaning, 238
setting up, 147-150
mouse port, 46
MPEG-2 decoder board, 67-68, 194-195
MSCDEX, 159-160
MS-DOS compatibility mode, 173-174
Multimedia Extension (MMX), 27-28
multipliers, CPU, 31, 93

NLX specification, 16

operating system, installing (*see* Windows 95)
overlay software, 140-141

parallel ports, 12, 45
parity, memory, 104-105
Partition Magic, 136
partitioning, hard drive, 135-137
parts, PC, 6-76
buying, 79-80
case, 7, 13-17
drive bays in, 14-15
manufacturers, 17
mechanical specifications, 15-16
types, 13-14
checklist, 77-79
CPU, 26-32
AMD, 28-29
clock speed, 31
cooling, 30
Cyrix, 29
Intel, 27-28
upgrades, 31-32
voltages, 30-31
drive system, 9-10, 56-69
backup drive, 68-69
CD-ROM drive, 64-65
controllers, 56-61
DVD drive, 65-68
floppy drive, 61
hard drive, 62-64
game port, 12
I/O ports, 12
joystick, 74-76
keyboard, 12-13, 73-74
modem, 69-72
drivers, 71-72
internal vs. external, 70
manufacturers, 72
speed, 71
monitor, 52-53
motherboard, 8-9, 21-26, 38-49
BIOS, 38-39
chipsets/controllers, 40-47
expansion slots/buses, 23-26
form factor, 23
manufacturers, 47-49
ports, 45-46
upgrades, 47
mouse, 12-13, 72-73
power supply, 7-8, 17-20
choosing, 20
connectors, 18-19
manufacturers, 20
mounting points, 19-20

Jameco Part number 151829

RAM, 32-38
  cache RAM, 35-36
  manufacturers, 38
  and SIMM specifications, 34-35
  types, 32-34
  upgrading, 36-38
sound board, 11-12, 53-56
  CD audio connector, 55
  CD-ROM interface, 54
  manufacturers, 55-56
  MIDI memory, 55
  MIDI/game port, 54-55
  speakers, 55
video system, 10-11, 49-53
  BIOS, 51
  controller, 10
  drivers, 51
  manufacturers, 52
  memory, 50-51
  resolution/color depth, 49-50
  upgrades, 52
PCI (*see* Peripheral Component Interconnect)
Pentium Classic CPU, 27
Pentium II CPU, 28
Pentium motherboards, chipsets on, 40
Pentium OverDrive CPU, 28
PentiumMMX CPU, 27-28
PentiumPro CPU, 27
  chipsets with, 45
Peripheral Component Interconnect (PCI), 24-25
Peripheral configuration menu (CMOS Setup), 212-215
planning phase, 1
plug-and-play configuration menu (CMOS Setup), 219-221
plug-and-play (PnP), 25, 153, 230
ports:
  disabling, 112-113
  game, 12, 75
  input/output (I/O), 12
  motherboard, 45-46
  video, 112-113
POST codes, 108-111
power management menu (CMOS Setup), 217-219
power supply, 7-8, 17-20
  choosing, 20
  connectors for, 18-19
  fitting, 15
  installing, 87-88
  manufacturers of, 20
  mounting points for, 19-20
  preconfiguring, 87
  upgrading, 88
powered speakers, 11, 55
  cleaning, 236-237
preventive maintenance, 231-249
  cleaning, 235-238
    air intake, 236
    case, 236
    fans/filters, 244
    floppy drive, 240
    keyboard, 237
    monitor, 237-238
    mouse, 238
    speakers, 236-237
    tape drive, 240-241
  data protection, 231-235
    CMOS backups, 234-235
    file backups, 232-234
  external checks, 238-243
    cables, 239
    CD tray, 241
    color purity of monitor, 242-243
    floppy drive, 240
    sound system, 241-242
    tape drive, 240-241
  final test, 248-249
  hard drive, 246-248
    boot disk, updating of, 247
    Defrag utility, running, 248
    ScanDisk utility, running, 247-248
  internal checks, 243-246
    cables, 245
    CPU, 246
    drive mounting, 246
    expansion boards, 244-245
    filters, 244
    memory, 245-246
  joystick, 75
  mouse, 73

Jameco Part number 151829

primary drive, 132-133, 182-183
primary IDE menu (CMOS Setup), 206-207
printer, for CMOS backups, 234
processor *[see* Central Processing Unit (CPU)]
purchasing PC components, 79-80

QUERTY keyboard, 74

Random Access Memory (RAM), 32-38
 Burst Extended Data Output (BEDO RAM), 33
 cache, 35-36
 cache RAM, 35-36
  installing, 105-106
 Dynamic (DRAM), 32-33
 Extended Data Output (EDO RAM), 33
 Fast Page Mode (FPM RAM), 33
 installing, 96-106
  bank, filling in, 98-99
  cache RAM, 105-106
  and memory parity, 104-105
  and SIMM combinations, 99-104
  snapping in SIMMs/DIMMs, 97-98
  manufacturers of, 38
  and SIMM specifications, 34-35
  Static (SRAM), 34
  sufficient amount of, 36
  types, 32-34
  upgrading, 36-38
Real Time Clock (RTC), 107
reasons for building a PC, 1-3
  advantages, 2
  disadvantages, 2
reboots, spontaneous, 125-126
recycling, 4-5
registry files, missing, 171-172
regulator, voltage, 30-31
repairs:
  costs of, 5-6
  motherboard, 111
(See also troubleshooting)
resolution, of video board, 49-50, 113-114
riser card, 16
RTC (Real Time Clock), 107

ScanDisk utility, 247-248
SCSI (Small Computer Systems Interface), 24, 130-131
SCSI CD-ROM drives, 158
SCSI controllers, 57-61
 BIOS, 60
 drivers, 60, 141
 and EIDE, 58-60
 installing, 130
 manufacturers of, 60-61
 upgrading, 143
SCSI hard drives
 configuration of, 135
 identification of, 133
SDRAM (Synchronous DRAM), 33-34
secondary drive, 132-133, 182-183
secondary IDE menu (CMOS Setup), 206-207
security menu (CMOS Setup), 223-226
seek time, 64
sequential data transfer rate, 189-190
serial ports, 12, 45
sharp edges, 85-86
SIMMs (Single Inline Memory Modules), 9, 32, 34-37
 combinations of, 99-104
 double-sided, 37
 installing, 97-99
 specifications for, 34-35
slack space, 136
slave, 132-133, 182-183
slots (*see* expansion slots/buses)
SmartCom, 71
sound board(s), 11-12, 53-56, 150-156
 CD audio connector on, 55

Jameco Part number 151829

CD-ROM interface, 54, 151-152
configuring, 150-152
drivers for, 153-154
installing, 152-153
manufacturers of, 55-56
MIDI memory, 55
MIDI/game port on, 54-55, 152
and PnP technology, 153
speakers with, 55
troubleshooting, 11-12, 154-156
sound system, checking, 241-242
speakers, powered, 11, 55
cleaning, 236-237
spontaneous reboots, 125-126
SRAM (Static RAM), 34
stalls, 125-126
start-up files, creating, 144-147
static electricity, 81-82
Static RAM (SRAM), 34
Supermicro, 28
SuperStor, 173
SVGA monitor, 53
Synchronous DRAM (SDRAM), 33-34
SYSTEM.DAT, 171-172

tape drives, cleaning, 240-241
testing:
CD-ROM drive, 160
final preventive maintenance test, 248-249
hard drive, 141
initial, 121-126
CMOS Setup, 122-123
power up, 121-122
troubleshooting, 123-126
mouse, 148-149
thermal grease, 95
tools, for PC assembly, 80-81
tower cases, 14
transfer speed, 64
troubleshooting, 4-6
advantages, 5-6
CD-ROM drive, 160-162
disadvantages, 5
DVD drive, 196-198
floppy drive system, 119-120
golden rule of, 6
hard drive, 142-143
initial testing, 123-126
joystick, 187-188
keyboard, 117
motherboard, 108-111
mouse, 149-150
sound board, 11-12, 154-156
upgrading by, 4-5
video system, 114
Windows 95 installation, 169-174
Tyan, 28

UMA (Upper Memory Area), 60
Universal Serial Bus (USB), 25-26, 230
upgrading, 3-5
advantages, 4
BIOS, 38-39, 198-201
cache RAM, 106
case, 7, 86
cost of, 4
CPU, 31-32
disadvantages, 3-4
drive controllers, 120
floppy drives, 120-121
hard drive controller, 143
keyboard, 117
memory, 36-38
motherboard, 47
mouse, 149
power supply, 88
and recycling, 4-5
sound system, 154
by troubleshooting, 4-5
video controller, 114, 116
video system, 52
Upper Memory Area (UMA), 60
USB (Universal Serial Bus), 230
USER.DAT, 171-172

VESA (*see* Video Electronics Standards Association)
video BIOS, 51
video boards
color depth of, 50
manufacturers of, 52
resolution of, 49-50

Jameco Part number 151829

video controllers, 10, 47, 49
 installing, 113
 upgrading, 114, 116
Video Electronics Standards
  Association (VESA), 24, 51
Video Local Bus (VLB), 24
video memory, 50-51
video system, 10-11, 49-53
 BIOS, 51
 drivers for, 51
 installing, 112-116
  controller board, 113, 114,
    116
  monitor, connecting, 113
  ports, 112-113
  resolutions, choosing,
    113-114
  troubleshooting, 114
 memory, 50-51
 optimizing, under Windows
    95, 174-175
 resolution/color depth, 49-50
 troubleshooting, 114
 upgrades of, 52, 114, 116
virtual memory, adjusting,
  under Windows 95, 176-178
viruses, checking for, 167
VLB (Video Local Bus), 24
voltages, CPU, 30-31
voltage jumper, 30
voltage Regulator, 30-31
Voltage Regulator Module
  (VRM), 93
VRM (Voltage Regulator
  Module), 93
"VxD error message, 171

Western Digital, 170
Windows 3.1x, 116
Windows 95, 82-83,
  165-179
 optimization of, 174-179
 CD-ROM drive, 178-179
 hard drive, 175-178
 video, 174-175
preparing for installation of,
  165-168
 BIOS virus checking, disabling of, 166-167
 hard drive, 167-168
 hardware, identifying, 166,
  167
 start-up files, 168
 viruses, checking for, 167
start-up disk, creating,
  168-169
troubleshooting, 169-174
Windows drivers, with video
 cards, 51
Windows NT, 27, 28
wiring, of case, 90, 91
work area, 84

Y cables, 18, 20

Jameco Part number 151829


Hardware
$19.95 U.S.A.
Learn how to build a complete, economical IBM-compatible PC from scratch!
Building your own PC is the way to go. You get exactly the system you want, save money, and have fun in the process. Stephen Bigelow has taught thousands of online students — including rank beginners — to construct the customized PC of their dreams. He's put all the tips, tricks, and techniques needed for success into this handy, step-by-step reference. From power supply through peripherals, you'll learn how to:
Choose your components
Assemble them in quick, efficient order
Test the system
Troubleshoot with confidence (especially for novices)
Take advantage of upgrades
Install and optimize Windows 95
Visit us on the World Wide Web at www.tabelectronics.com
Cover Design: Paul Agresti
McGraw-Hill
6 39785 30371 8
ISBN 0-07-037139-3
90000
9 780070 371392